Chlorine Test Kit High/Low Product Code: 11385



Information

The Lovibond® Comparator 2000+ System is an extremely versatile modular system for testing water. It is simple to use yet is uncompromising in terms of precision and reproducibility of results. Unlike other comparators, the 2000+ uses a prism enabling colour matching in the same field of view. The Comparator itself is robust compact and portable allowing for ease of use in any environment. Longer path length cells can be used for lower concentration analysis. A diffuser plate is also used to allow the measurement of turbid samples.

Fade free glass colour standards are used in the comparator discs to ensure long term stability and accurate colour matching.

Full disc readings for each Chlorine disc can be found in the table below:

Test Disc code Disc Readings

Chlorine 3/40A 0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 1 mg/l

Chlorine High 3/2ARP 5, 10, 15, 20, 25, 30, 35, 40, 50 mg/l total Cl2

Kit Content

- · Carry case with inlay
- Comparator 2000 + unit
- · High Range Chlorine disc
- · Low Range Chlorine disc

Contact us

Vernon Morris Utility Solutions Ltd Airfield View, Hawarden Industrial Park, Deeside, Flintshire, CH5 3QW, United Kingdom Telephone: 01244 660794

©2024 Vernon Morris Utility Solutions Ltd.

All information is correct at time of publishing, however we reserve the right to change any information at any time.







Vernon Morris Utility Solutions Ltd

Specialist Suppliers to the Utilities

- 2 x Plastic 10ml cells
- Stirring rod
- Cleaning brush
- Box of 100 DPD 1 tablets
- · Box of 100 DPD 3 tablets
- · Potassium Iodide tablets
- · Acidifying GP tablets
- Instructions

Kits also available in High only & Low only

Availability: In Stock

£POA

Please enquire for the latest pricing & availability information for this item

Contact us

Vernon Morris Utility Solutions Ltd Airfield View, Hawarden Industrial Park, Deeside, Flintshire, CH5 3QW, United Kingdom Telephone: 01244 660794

©2024 Vernon Morris Utility Solutions Ltd.

All information is correct at time of publishing, however we reserve the right to change any information at any time.



